



SURE FLAME[®]

SE405

CONSTRUCTION HEATERS



January 5, 2011 Rev: 1.1
SERVICE AND MAINTENANCE MANUAL
PLEASE RETAIN FOR FUTURE REFERENCE

SURE FLAME[®] PRODUCTS

A Division of Haul-All Equipment Ltd.
4115 - 18 Avenue North
Lethbridge, Alberta T1H 5G1
www.sureflame.ca

SE405 CONSTRUCTION HEATER



GENERAL HAZARD WARNING

Failure to comply with the precautions and instructions provided with this heater, can result in death, serious bodily injury and property loss or damage from hazards of fire, explosion, burn, asphyxiation, carbon monoxide poisoning, and/or electrical shock.

Only persons who can understand and follow the instructions should use or service this heater.

If you need assistance or heater information such as an instruction manual, labels, etc. Contact the manufacturer.



WARNING

Fire, burn, inhalation, and explosion hazard. Keep solid combustibles, such as building materials, paper or cardboard, a safe distance away from the heater as recommended by the instructions. Never use the heater in spaces which do or may contain volatile or airborne combustibles, or products such as gasoline, solvents, paint thinner, dust particles or unknown chemicals.



WARNING

Not for home or recreational vehicle use

READ THIS WARNING FIRST !

The heater is designed and approved for use as a construction heater under ANSI Z83.7a-2007. The primary purpose of construction heaters is to provide temporary heating of buildings under construction, alteration, or repair and to provide temporary emergency heat. Properly used, the heater provides safe economical heating. Products of combustion are vented into the area being heated.

The heater is not designed as an Unvented Gas Fired Room Heater under ANSI-Z21.11.2 and should not be used in the home.

ANSI A119.2(NFPA 501C)-1987 Recreational Vehicle Standard prohibits the installation or storage of LP-Gas containers even temporarily inside any recreational vehicle. The standard also prohibits the use of Unvented Heaters in such vehicles.

Installation must comply with local codes, or in the absence of local codes, with the *National Fuel Gas Code ANSI Z223.1/NFPA 54* and the *Standard for the Storage and Handling of Liquefied Petroleum Gases ANSI/NFPA 58*.

We cannot anticipate every use which may be made for our heaters. CHECK WITH YOUR LOCAL FIRE SAFETY AUTHORITY IF YOU HAVE QUESTIONS ABOUT LOCAL REGULATIONS.

Other standards govern the use of fuel gases and heat producing products in specific applications. Your local authority can advise you about these.

SE405 CONSTRUCTION HEATER

FOR YOUR SAFETY

**DO NOT USE THIS HEATER IN A SPACE WHERE
GASOLINE OR OTHER LIQUIDS HAVING
FLAMMABLE VAPOURS ARE STORED OR USED.**

CONTENTS

| | |
|---|----|
| Specifications | 5 |
| Installation | 6 |
| Installation Using A Propane Supply Tank | 7 |
| Installation For Natural Gas Applications | 7 |
| Operating Instructions | 8 |
| Preventative Maintenance | 9 |
| Troubleshooting | 10 |
| SE405 Connection Wiring Diagram | 12 |
| SE405 Ladder Wiring Diagram | 13 |
| SE405 Heater Parts | 14 |
| LPG - Propane Fuel Vaporization Rate | 16 |

SPECIFICATIONS

Model No. SE405 Construction Heaters

Gases: Natural or Propane
 Capacity: 400,000 Btu/h (120 kW) maximum
 Orifice Size: 11/64" (x6)
 Inlet Air Flow: 1150 cfm (545 l/s) at 20°C (68°F)
 Outlet Air Flow: 1800 cfm (850 l/s) at 186°C (367°F)
 Electrical Rating: 120 volts, 60 Hz., 7.5 amps, single phase
 Minimum Temperature: -30°C (-22°F)
 Maximum Duct Length: 25' (7.6 m)
 Duct Diameter: 18"
 Max. Duct Static Pressure: .49"

| | | |
|-------------|----------------|-------------------|
| Gas Supply: | _____ | _____ |
| | Inlet Pressure | Manifold Pressure |
| | Max. W.C. | Max.W.C. |
| | 14" (3500 Pa) | 5.0" (1250 Pa) |
| | 8.0" (2000 Pa) | |

(Minimum inlet pressure is for purpose of input adjustment)

INSTALLATION

The Sure Flame Model SE405 Construction Heater is a direct fired gas heater intended to be used primarily for the temporary heating of buildings under construction, alteration, or repair. Since all the products of combustion are released into the area being heated, it is imperative that adequate ventilation is provided.

- 1 Install the heater in a horizontal position at least 10 feet (3m) from any LP-gas container. Allow the following clearances from any combustible materials:

| | | | |
|---------------|-----------------|--------|----------------|
| Front Outlet: | 12 feet (3.7 m) | Sides: | 2 feet (0.6 m) |
| Intake: | 2 feet (0.6 m) | Top: | 5 feet (1.5 m) |

Front Outlet must not be directed at any LP-gas container within 20 feet (6 m).

The heater is designed for use with up to 25 feet of 18" ductwork. Ductwork must be able to handle temperatures of up to 300°F. Only duckwork supplied by the manufacture shall be use with this heater.

Also make sure that no flammable vapours are present in the space where the heater is being used.

- 2 When connecting the heater to a natural gas or propane supply line ensure that the pressure at the heater inlet is within the specified range. Excessive pressure (over 1/2" psi) will damage the controls and void the warranty.
- 3 Visually inspect the hose assembly and ensure that it is protected from traffic, building materials, and contact with hot surfaces. If it is evident that there is excessive abrasion or wear, or the hose is cut, it must be replaced.
- 4 After installation, check the hose assembly for gas leaks by applying a water and soap solution to each connection.
- 5 Connect the heater to an adequate 120 volt electrical supply as specified on the rating plate. For protection against shock hazard the supply cord must be plugged directly into a properly grounded three-prong receptacle.

Note: Low Voltage (long extension cord or too many items on circuit) will shorten motor life.

INSTALLATION USING A PROPANE SUPPLY TANK

- 1 When installing the heater for use with propane gas, set the gas selector valve to “Propane” and lock in position.
- 2 Arrange the propane supply system to provide for vapour withdrawal from the operating container. Supplying liquid propane to the heater is dangerous and will damage the components. Another regulator must be installed on the heater to reduce the pressure from this regulator to a maximum inlet pressure of 1/2 psi.
- 3 Ensure that for the surrounding temperature the size and capacity of the propane supply container is adequate to provide the rated Btu/h input to the heater.
- 4 Turn off the propane supply valve at the container when the heater is not in use.
- 5 The installation must conform with local codes, or in the absence of local codes, with the *Standard for the Storage and Handling of Liquefied Petroleum Gases, ANSI/NFPA 58*.
- 6 When the heater is to be stored indoors the propane container must be disconnected from the heater and the container moved away and stored in accordance with the above national standards.

INSTALLATION FOR NATURAL GAS APPLICATIONS

- 1 When installing the heater for use with natural gas, set the gas selector valve to the “Natural” position.
- 2 A regulator must be installed on the heater to ensure that the pressure to the heater does not exceed 1/2 psi inlet pressure.
- 3 The installation of this heater to a natural gas supply must conform with all applicable local codes, or in the absence of local codes, with the *National Fuel Gas Code ANSI Z223.1/NFPA 54*.

HEATER OPERATING INSTRUCTIONS

1) Set GAS SELECTOR VALVE to gas being used. The conversion shall only be done by the owner or lessor of the equipment.

NOTE: When using Propane Gas the SELECTOR VALVE must be locked in position.

2) Ensure valve is in the "ON" position.

3) Connect Power - 120 volt supply. Open gas supply.

4) Set switch to "HEAT" mode.

5) Push "START" button.

6) If equipped with a thermostat, set thermostat to desired temperature.

To stop, push the "STOP" button and turn gas off. Fan will continue operating for 60 seconds.

The appliance area should be kept clear and free from combustible materials, gasoline, and other flammable vapours and liquids.

Ensure that the flow of supply air and combustion gases is not obstructed.

The installation and operation of the heater shall comply with the code requirements specified by the authorities having jurisdiction.

**THE INSTALLATION AND MAINTENANCE OF THE
HEATER MUST BE ACCOMPLISHED BY A
QUALIFIED SERVICE PERSON.**

FAN OPERATING INSTRUCTIONS

1) Set switch to "FAN" mode.

2) Push "START" button.

To stop push the "STOP" button.

PREVENTIVE MAINTENANCE

Sure Flame construction heaters are built to withstand the rigours of operating on construction sites, in mining applications, and in a multitude of other locations where heaters are used. To maintain the reliable performance required it is necessary to do a certain amount of regular maintenance.

PERIODIC MAINTENANCE:

Weekly:

| | |
|-------------------------|--|
| Gas Hose | Check for cracks or damaged connectors |
| Obstruction of Air flow | Clean & remove debris |

Monthly:

| | |
|--------------------|--|
| Cords & Connectors | Check for cracks, exposed wires & dirt in electrical connectors. Clean with water and dry out before connecting power. |
| Physical Integrity | Check for damage to body, louvers and inlet screens that may impact combustion quality. |

End of season:

| | |
|--------------------------------|--|
| Manifold Pressure | Check for nominal pressure specified in specification label. Adjust regulator pressure if necessary. |
| Fan Blade | Remove dirt buildup. Replace damaged or unbalanced blades. |
| Strainer | Inspect and clean if necessary. |
| Combustion Chamber & Flame Rod | Remove nose cone and inspect inside for integrity. Remove accumulated carbon deposits with a wire brush. Clean flame rod with solvent or emery cloth. Inspect insulator for cracks. Check flame rod tip for 1/8" gap to ground. Install nose cone. |
| Gas leaks | Using soapy water or gas leak detector check all gas connections for leaks |
| Air Tubes | Verify that air tubes are not blocked and that they are securely attached with a 1/8" gap from the combustion chamber wall. |
| Wiring & Drain holes | Check the electrical box for loose or overheated wires and connectors. Using a dry cloth or compressed air clean bottom drain holes if necessary. Check for integrity of cover seal. |

TROUBLESHOOTING CHART

Motor does not start

| Symptom | Problem |
|---|--|
| No green power light (after pressing start button) | No electrical supply |
| | Fuse or transformer failure (motor starts when manual button on motor relay is pressed) |
| | Start switch failure. (After engaging power relay test button green light turns on) |
| Green light comes on when start button pressed, but goes off when released | Power relay failure |
| | Stop switch failure |
| Green light is on. Motor does not start in either Heat or Fan mode | Motor relay failure. Motor won't start (starts after manual button is pressed in motor relay). |
| | Motor failure |
| Green light is on. Motor does not start in Heat mode, but does start in Fan mode. No error lights on flame controller | Thermostat failure (starts OK with Jumper Plug) |
| | Thermostat and jumper not connected |
| Green light is on. Motor does not start in Heat mode, but does start in Fan mode. Error light on flame controller is on or flashing | Flame control failure |

Motor starts, but no flame

| Symptom | Problem |
|--|---|
| Blower Motor starts, but burner does not ignite. Flame controller error light flashes 2 times. No gas odor at heater outlet. | Flame control failure |
| | Flame rod wet |
| Blower Motor starts, but burner does not ignite. Flame controller error light flashes 3 times. No gas odor at heater outlet. | Manual valve closed |
| | Limit switch failure. No continuity between terminals |
| | Air switch failure, air switch set to too high a pressure, or air switch tubes blocked or in wrong position |
| | Solenoid valve failure |
| | Second stage regulator set too high, solenoid valve will not open |
| | Upstream regulators installed backwards |
| | Flame control failure |
| | Poor quality power (such as from a generator). Dirty signal or wrong hertz |
| | Motor running in reverse (incorrect wiring on replacement) |
| | Ignitor failure. Cracked ceramic or Incorrect gap to burner plate (should be 1/8") |
| Blower Motor starts, but burner does not ignite. Flame controller error light flashes 3 times. Gas odor at heater outlet. | Burner not grounded |
| | Hose diameter too small and/or hose too long, blocked hose |
| | Low inlet pressure |
| | Gas selector valve set to wrong fuel |
| | Second stage regulator set too low |
| Main regulator setting too low | |

TROUBLESHOOTING CHART (cont.)


Heater starts but then fails

| Symptom | Problem |
|---|--|
| Heater starts, but flame goes out about 4 seconds after igniting | Flame rod failure Flame control failure |
| Heater starts, but fails after running for a period of time | Changeover valve set to propane when connected to natural gas Low heat, High CO ; Random shutdown; Second stage regulator set too low Main regulator setting too low Strainer plugged or dirty Outlet duct too long or obstructed Limit switch failure |
| Heater sensitive to wind gusts | Air switch set to too high a pressure |
| Excessive Flame; Heater stops after a few minutes of function (High Limit Switch opens) | Nose cone gap too small Changeover valve set to natural gas when connected to propane. Connected to liquid propane Main regulator setting too high |
| Blower motor overheats in function (Thermal protection in motor); Random shutdown | Poor quality power (such as from a generator). Dirty signal or wrong hertz |

Other Problems

| Symptom | Problem |
|--|---|
| Motor runs as soon as heater is plugged in. | Motor relay failure Start switch failure |
| Normal function; Heater stops only if unplugged | Stop switch failure |
| Flame interrupts in function. Frost on propane tank | Propane tank too small to vapourize fast enough, tank freezes |
| Burner unstable | Nose cone gap too big |
| Irregular flame in combustion chamber. Excessive carbon deposit in combustion chamber; Burner unstable | Burner orifices plugged or dirty |
| Gas odor when no call for heat. | Solenoid valve leak |
| Excessive heater noise. Vibrations | Damaged or unbalanced fan blade |
| Operates in only heater mode, or only fan mode | Toggle switch failure |
| Normal function-when inlet obstructed flame shooting out (High Limit Switch opens) | Air switch failure Air switch set to too low a pressure |


SE405 Connection Wiring Diagram




Rev 1.0

Note:: All wires 18 Ga STR TEW 600V unless otherwise specified.

SE405 Ladder Wiring Diagram



SE405 HEATER PARTS DIAGRAM



| Ref Part No. | Description | Ref Part No. | Description |
|--------------|----------------------|--------------|--------------------------------|
| 1 SE-4091 | Top Cover | 25 SE-4078 | Burner Washer |
| 2 9843 | Limit Switch | 26 9831 | Burner Head |
| 3 7780 | Nose Cone Spacer | 27 SE-4712 | Gas Line Assembly |
| 4 SE-4018 | Nose Cone | 28 9834 | Flare Adapter |
| 5 SE-4506 | Duct Adapter | 29 SE-4718 | Gas Selector Valve with Handle |
| 6 SE-4507 | Combustion Chamber | 30 SE-4510 | Inlet Coupling |
| 7 SE-4109 | Copper Air Tube | 31 9830 | Gas Valve |
| 8 7379 | Tubing Clamp | 33 SE-4715 | Thermostat Assembly with Cord |
| 9 SE-4027 | Front Leg | 34 2453 | Thermostat |
| 10 SE-4090 | Bottom Panel | 41 9872 | Relay |
| 11 1525 | Fan Blade | 42 9879 | Start Switch |
| 12 9827 | Motor | 43 9880 | Stop Switch |
| 13 6119 | Semi-Pneumatic Wheel | 44 9881 | Heat / Fan Switch |
| 14 SE-4511 | Wheel Bracket | 45 9882 | Switch Gasket |
| 15 SE-4093 | Blower Plate | 46 SE-4716 | Thermostat Jumper Plug |
| 16 SE-4509 | Motor Mount | 47 WRS-163 | Thermostat Receptacle |
| 17 SE-4508 | Control Box | 49 9828 | Flame Control |
| 18 SE-4076 | Right Inlet Panel | 50 9823 | Terminal Block |
| 19 SE-4512 | Control Box Lid | 51 SE-4719 | Air Switch |
| 20 SE-4070 | Left Inlet Panel | 52 9884 | Fuse, 2A/250V, Fast Acting 3AG |
| 22 SE-7430 | Electrode Assembly | 53 9883 | Fuse Holder |
| 23 9833 | Flare Elbow | 54 4510 | 24V 40VA Transformer |
| 24 9832 | Bowed Snap Ring | 55 SE-4521 | 18" duct adapter (not shown) |

LPG - PROPANE FUEL VAPORIZATION RATE

The following chart shows the amount of BTU's that various sizes of tanks will produce on the average at specific temperatures and regular atmospheric conditions.

| Tank Size Gallons (Pounds) | Maximum intermittent withdrawal rate (BTU/hr) without tank frosting* if lowest outdoor temperature (average for 24 hours) reaches. | | | | | | | |
|----------------------------------|---|---------|---------|---------|---------|---------|---------|---------|
| | +40 F. | +30 F. | +20 F. | +10 F. | 0 F. | -10 F. | -20 F. | -30 F. |
| 150 (600) | 214,900 | 187,900 | 161,800 | 148,000 | 134,700 | 132,400 | 108,800 | 107,100 |
| 250 (1000) | 288,100 | 251,800 | 216,800 | 198,400 | 180,600 | 177,400 | 145,800 | 143,500 |
| 500 (2000) | 478,800 | 418,600 | 360,400 | 329,700 | 300,100 | 294,800 | 242,300 | 238,600 |
| 1000 (4000) | 852,800 | 745,600 | 641,900 | 587,200 | 534,500 | 525,400 | 431,600 | 425,000 |

* Frosting on the outside of the tank acts as an insulator, reducing the vaporization rate.

MAXIMUM BTU CONTENT (PROPANE)

The following table shows the maximum BTU's that a cylinder contains.

| CYLINDER SIZE | BTU CONTENT |
|-----------------|-------------|
| 100 pound | 2,159,100 |
| 250 gallon USA | 22,922,500 |
| 500 gallon USA | 45,845,000 |
| 1000 gallon USA | 91,690,000 |

CAUTION: In extremely cold weather it is impossible to completely empty a propane cylinder.

PRESSURE & FLOW EQUIVALENTS

| | | |
|--------------------------|---------------------|-------------------|
| 1 Std. Atmosphere = | 14.73 lb./sq. in. = | 1.014 bar |
| 1" Water Column (W.C.) = | 0.58 oz./sq. in. = | 2.49 millibar |
| 11" Water Column = | 0.4 lb./sq. in. = | 27.39 millibar |
| 1 lb./sq. in. (psig) = | 27.71" W.C. = | 0.0689 bar |
| 1" Mercury = | 0.49 psig = | 33.86 millibar |
| 1 Std. Cubic Ft./Hr. = | 2,500 BTU/Hr. = | 0.02832 cu. m/hr. |
| 1 BTU/Hr. = | 0.2931 Watts | |